# Laser Scan Space Manager LSSM PanoMap

Provide comprehensive lifecycle support for nuclear facilities



#### Key Advantages

- Manage scans as a large-scale 3D Model
- Multiple output formats:
  - Panoramic 3D Bitmap
  - 3D Surface Model
  - Library-based Intelligent 3D Model
- Available extensive libraries of intelligent 3D objects
- Extensive experience with interfaces and conversions to other CAD systems



#### **Nuclear Plant Application**

- Support dose reduction initiative
- Permanent shielding design
- Strainer design and installation
- Steam generator replacement
- Equipment removal/replacement projects



- General engineering mods
- Scaffolding design/installation support
- Access to radiation data
- Training



- Real-time display from permanent radiation monitors
- Gamma scanning integration
- Replacement of surrogate travel applications
- Outage planning support refueling floor management



- As-built plant documentation
- Piping insulation replacement
- Pre-job briefings
- Alloy 600 mitigation



- NRC GL 2008-01 pipe slope
- Emergency response
- Tribal knowledge retention/transfer
- Interface to documents



# Laser Scan Space Manager LSSM PanoMap

- Integrates all scan data
- Powerful registration capability, automatic registration support
- No limit to number of scans
- Scans are object-oriented



# Laser Scan Space Manager LSSM PanoMap (continued)

- Integrates with CAD design software
- Variety of output formats
- Priority is given to automatic conversions



# Laser Scan Space Manager LSSM PanoMap (continued)

- Data generated can be used directly for project applications
- The scan format used is much smaller than "Point Cloud Data"
- Works with any laser scanner



#### **LSSM Modules**

- PanoMap
  - Lite
  - → Full (Modeling and other advanced functions)
- Scan Manager
- Related Applications
  - → Model Review
  - → MacroCAD
  - Plant/CMS Applications



#### LSSM Functions

- Project set-up
- Management of scan database
- Registration of scans
- Integration with 3D plant model



#### PanoMap Functions

- Powerful 3D viewer of scan data in photo-realistic format
- Review of scan data
- Redlining and annotations
- Dimensioning
- Overlay digital photographs



#### PanoMap Functions

(continued)

- Intelligent model conversion
- Access to Asset Management Database
- Conversion to 3D surface model
- Creation of 3D intelligent model



#### **Dose Reduction Tool**

- Reduction of time spent in radiation areas
- Major support for plant walkdowns
- Better planning



#### **Dose Reduction Tool**

(continued)

- Improved training for the construction crews
- Reduction of design errors
- Minimize surprises
- River Bend OE Report



#### Plant/CMS Support

- Interference checking
- Conversion to other CAD systems
- Drawing production




#### Plant/CMS Support

(continued)

- □ Integrated review of scan models and 3D models
- Access to information asset data
- Access to documents



# **Equipment Removal Simulation**






# **Equipment Removal Simulation**



**CSA** 

# **Equipment Removal Simulation**




CSA

#### Integration with Radiation Data






#### Integration with Radiation Data







#### Integration with Radiation Data


















			-	The same				
Microsoft I	Excel - SlopedPi	pe_risol.xls						_   X
File Edi	t <u>V</u> iew <u>I</u> nser	t Format Tools	<u>D</u> ata <u>W</u> indow	<u>H</u> elp			Type a question for help	8 ×
A1	▼ fs	,						
A	В		С	D	Е	F	G	
1				CSA Plant CI	MS			
	_ <del>-</del> -							
2				PERRY				
3			Summary of	Processed Pipe Li	nes and Objects	5	Date: Dec 02 2008	
4							Rev No: 1	
5		1						
6								
7	OBJECT	PIPELINE		ACAD DRAWING	SNAP SHOT OF I	DWG	ISO DRAWING	
8								
9		4"-D1-2-001			XPLHPC001_Mode		\304-0701-00101.TIF	
10		10"-L2-4-002			XPLHPC002_Mode		\304-0701-00102.TIF	
11		16"-D1-2-003			XPLHPC003_Mode		\304-0701-00103.TIF	
12		6"-L1-2-004			XPLHPC004_Mode		\304-0701-00105.TIF	
13		6"-D1-2-005			XPLHPC005_Mode		\304-0701-00105.TIF	
14		16"-L1-2-006			XPLHPC006_Mode		\304-0701-00106.TIF	
15		24"-L1-2-001		XPLLPC001.dwg	XPLLPC001_Mode		\304-0705-00101.TIF	
16 17		24"-L1-2-001 24"-L1-2-003		XPLLPC002.dwg	XPLLPC002_Mode		\304-0705-00101.TIF	
18		16"-L1-2-003		XPLLPC003.dwg XPLLPC004.dwg	XPLLPC003_Mode		\304-0705-00102.TIF	
19		4"-G1-2-005			XPLLPC004_Mode		\304-0705-00102.TIF	
20		14"-G1-2-005		XPLLPC005.dwg	XPLLPC005_Mode		\304-0705-00103.1IF	
21	PLLPC007	14"-G1-2-000		XPLLPC000.dwg	XPLLPC000_Mode		\304-0705-00105.TIF	
22		12"-G1-2-007			XPLLPC007_Mode		\304-0705-00105.TIF	
23		4"-G1-2-001			XPLRHR001 Mode		\304-0641-00105.PDF	
24		18"-G1-2-002			XPLRHR002 Mode		\304-0641-00105.PDF	
25		18"-G1-2-003			XPLRHR003 Mode		\304-0641-00106.PDF	
26		18"-G1-2-004			XPLRHR004 Mode		\304-0641-00107.PDF	
27		18"-G1-2-005			XPLRHR005 Mode		\304-0641-00110.PDF	
28		18"-G1-2-006			XPLRHR006 Mode		\304-0641-00111.PDF	
29		18"-G1-2-007			XPLRHR007 Mode		\304-0641-00113.PDF	
30		24"-G1-2-008			XPLRHR008 Mode		\304-0641-0115.PDF	
31		18"-G1-2-009					\304-0641-00112.PDF	
32	PLRHR010	18"-G1-2-010		XPLRHR010.dwg	XPLRHR010 Mode	slope	\304-0641-00114.PDF	
33	PLRHR011	24"-G1-2-011		XPLRHR011.dwg	XPLRHR011 Mode	slope	\304-0641-00119.PDF	
34		6"-G1-2-012		XPLRHR012.dwq	XPLRHR012 Mode	slope	\304-0641-00116.PDF	
	ndex / PSRHR03	3 / PSRHR032 / PS	SRHR031 / PSRH	R030 / PSRHR029 / PSR	HR028 / PSRHR ◀			<b>₽</b>
Ready								11.
							THE RESERVE AND ADDRESS OF THE PARTY OF THE	



		•			_		-		_	_	_		_			
N I	Microsoft Excel - SlopedPipe_risol.xls															
	<u>File</u> <u>E</u> dit	<u>V</u> iew	<u>I</u> nsert F	ormat <u>T</u> oo	ls <u>D</u> ata	<u>W</u> indo	ow <u>H</u> elp						Type	a question for	help 🔻 🗕	. ₽ ×
	A1	•	fx Ba	ack												
	Α	В	С	D	E	F	G	Н	I	J	K	L	M	N	0	
1	Back						CSA	Plant	CMS							
2			PERRY													
3		PIPE SLOPE REPORT Date: Dec 02 2008														
4													Rev No: 1			
5													Page No:	1		
6			L1-2-004				PLLPC00	04								
7			PC004.dwg		XPLLPC	004_N	lodel.tif									
8			4-0705-001													
9			M WORK F				VORK POI				SEGMENT		REMARKS	S		
10		NO.	EL. (in)	TYPE	PIECE	NO.	EL. (in)	TYPE	PIECE	LENGTH (in)	(%)	(deg)				
11		l.,	2074 50	5.55		_	2004 50		_							
12		1			3	3	6934.52 7008.34		6		Vertical Vertical	89 90				
14	-	2			6	4	7008.34		8	13.82			Pocket o	n nodo 2		
15		4			8	5	7007.25		0B	60		-0.044	FUCKELU	II IIoue 3		
16		5			0B	6	7007.43		0D	60.63		0.16				
17		6			0D	7	6950.86		0G		Vertical	-90				
18		7			0G	8	6945.1		0H		Vertical	-90				
19		8	6945.1	FL	0H	9	6926.84	FL	0J	18.26	Vertical	-90				
20		9	6926.84	FL	0J	10	6923.96	FL	0K	2.88	Vertical	-89				
21																
22																
23																
24 25																
26																
27																
28																
29																
30																
31																
32																
33																
14 4	→ N / PLR	HR002	PLRHR00	1 / PLLPCO	08 / PLLPO	007 /	PLLPC006 /	PLLPC005	PLLPC004	4 PLLPC(   4						
Read	ly															































TVA	N SYSTEMS ASSOCIATES, INC.	5equo	CONFIGURATION   yah					PAGE: DATE: 01-30	-2008
PIPING BILL	OF MATERIAL : *ISORI_2007				R	EV. NO:	STATUS: STATUS DATE:		
STZE	DESCRIPTION						QUANTITY TAG NO		
MATERIAL:	c0					<b>.</b>			
	X 2" SCH.80 BW CONC. RED. SCH.80 BW TEE	RD TEE	CONC2 S	80 80	BW BW		1		
MATERIAL:	× × × × × × × × × × × × × × × × × × ×				-:-:-:-				
200-0-00-	SCH. 80 SR 90DEG. BW ELL		905	80	BW		2		
MATERIAL:	J5 C 5TL, ASTM A105, ANSI B16.36								
4 2	2" FORGED SLIP-ON FLG (PAIR)	FL	ASSEMBL FLANGE	50	FL		2		
MATERIAL:	L7 C STL, SMLS, ASME 5A234 GR WPB	, ANSI	B16.9						
5 3	SCH. 80 LR 90DEG. BW ELL	ELL	90L	80	BW		3		
MATERIAL:	MC	2222	333333333333333	2222		de:			
6 2	METAL HOSE 2" -WELD NIPPLE	FL	UNAFLEX				2		
MATERIAL:	P7 ASTM A106 GR B					<u> </u>			
7 3	SCH.80 PIPE	PIPE		80	BW	24'-11.31/32"	4		
MATERIAL:	PL 1.25 CR5 MO, SMLS, ASTM A335	GR P	11, ANSI B36.10			<del></del> -			
8 2	SCH.80 PIPE	PIPE		80	BW	1'-6.7/64"	6		




#### Redlining





#### **Dimensions**






#### Component Removal








#### Interference Review






#### Interference Review






#### Interference Review





#### Surface Model





#### Surface Model






# Integration with Digital Photographs






# Integration with Digital Photographs






# Access to Documents P&IDs






## Access to Documents P&IDs






**Modeled Geometry** 






#### Access to Asset Database






#### **Model from Scan Data**





#### **Model from Scan Data**




**CSA** 

### Jet Impingement Analysis






#### Jet Impingement Analysis





#### PanoMap Keyplan Access






## Drawing Production Dose Reduction Tool One of the Production Tool One of the Produc






#### **CAD/Scan Integration**



**CSA** 

### CAD/Scan Integration



**CSA** 

#### CAD/Surface Model





#### **Engineering Services**

- Creation, maintenance of Integrated Scan Model
- Conversion to other CAD formats
- Export redlining and dimensioning data



### Engineering Services

(continued)

- Integration with new CAD designs
- Import most popular scan formats
- Registration of scan data



#### Software Support

- Software License
- Training and Implementation
- Project consulting
- Custom development



#### Typical Project Implementation

- Field scanning work
- Creation/organization of scanning database
- Transform point clouds into PanoMap format



## Typical Project Implementation (continued)

- Scan registration
- Generate surface model
- Create intelligent model (optional)
- Transfer to other CAD systems



#### Plant/CMS Integration


- Full Plant/CMS Compatibility
- Object-oriented
- Single, unified plant database
- Interfaces to other CAD systems

Plant/CMS = Plant Configuration
Management System



#### CAD Conversions

#### **LEGACY PLANT CONVERSIONS**





## We appreciate your interest in CSA's technology.

**Contact Info:** 

CSA, Inc.

Olga Burger, VP Marketing

770-955-3518

burger.o@csaatl.com

