### Bruce A Successes in Internal Dose Reduction

Presented by Mike Murray Health Physicist, Bruce A Radiation Protection & Industrial Safety Department



#### **Bruce A Historical Performance**



Graph 1. Bruce A Dose Performance (Rem)

• Current year to date performance = 4.5% as of July 2010

Outage performance = 2%

Bruce A Nuclear Operations – In pursuit of sustainable performance excellence

Brunie Pul

42R

BRUCE A



### **CANDU Internal Dose Performance**

| CANDU 2009 Internal Dose Comparison |  |  |  |
|-------------------------------------|--|--|--|
| Station                             | 2009 Internal dose as a percentage of<br>whole body dose |  |  |
| Bruce A                             | 2009 - 8.7 %   |  |  |
| Bruce B                             | 2009 - 7.6 %   |  |  |
| Wolsung                             | Unit 3 – 47%<br>Unit 4 – 35%                             |  |  |
| TQNPC                               | 21.8%  |  |  |
| Darlington                          | 12.3%  |  |  |
| Pt. Lapreau                         | 3.0% (under refurbishment)                               |  |  |
| Gentilly                            | 15.7%  |  |  |
| Cernevoda                           | 13.9%  |  |  |

Bruce A 2010 YTD – 4.5%

Brunie Pul

42R

BRUCE A

Bruce A 2010 projected – 5.4%

## **Outage Trends**

| Outage | Internal Dose | % WB dose |  |
|--------|---------------|-----------|--|
|        | [Rem]         |           |  |
| A841   | 29.109        | 24.1      |  |
| A831   | 19.660        | 8.4       |  |
| A093   | 1.613         | 2.4       |  |
| A094   | 9.089 5.2     |           |  |
| A1031  | 6.715         | 2.4       |  |

Brute Pulle

42R

**BRUCE A** 

# How did we do it?

• Culture shift

42R

- Identification and repair of PHT leaks
- Use of Munter units during outages
- Use of Sperien disposable suits
- Reduction in tritium source term
- Unplugged time awareness
- Rigorous investigation of excessive internal dose
- Management focus and oversight

All internal dose is preventable.

## Culture Shift in Internal Dose

We went from

То

42R

It's just tritium dose, there is nothing we can do about it....we are already wearing plastic suits.

All internal dose is preventable

#### PHT Leak Rates & Leak Searches

- Numerous PHT leaks
- Leak search techniques improved
  - Use of engineering staff on reactor face
  - Use of mirrors to see behind greylocks
  - Observations at time of insulation removal
- Repair of identified leaks

### CSA Tritium & PHT Leak Rate Trends



## VVR Corrective and Preventative Maintenance

- Damper actuators were refurbished
- Age-degraded desiccant beds were changed out and depth of bed doubled
- Drier operating parameters, including temperature set-points and cycle time, were optimized.
- Return to service of the ESA Dryer
- Revision of air-purge procedure to allow VVR to remain in service during ice-plugs in vault.
  - Exhaust to CSA stack with air introduced at ESA.

# Use of Munters

- Munter units have been used in vaults since fall 2008
  - Performance has improved since then due to defined ownership and procedures for operation
- 2 units in the same vault used in most recent outages
  - During VBO 2 were placed in Unit 4, none in Unit 3 however they were effective at tritium mitigation in BOTH units

# Sperien Disposable Plastic Suits

- First used during fall 2008 for west shift campaign only
  - Observed internal dose for west shift workers to be about 2% of WBD
- Continued to increase usage
  - 24% in fall 2009 outages
    - <u>Recommended</u> suit usage in REPs
    - Not all staff qualified
  - 48% in spring 2010 outage
    - <u>Required</u> suit usage for most jobs in REPs
    - Most staff qualified

42R

- OJE performed for those not qualified
- Special permission had to be obtained to NOT wear the suit

## **Sperien Results**



#### **Reduction in Tritium Source Term**



## **Worker Practices**

- REPs revised to REQUIRE from RECOMMENDED
  - Emphasized unplugged time in REPs and briefings
    - Quantifying an unacceptable unplugged time had a big impact – shock value
    - **REQUIRED** Sperien suits
- REP quality, more applicable to work
  - Work group ownership of REP

42R

- Removal of information that does not apply to the work
- Rigorous investigation of excessive dose events (> 10 μCi/L)
  - Focus on internal dose as a metric on its own, performance review for individual differences

# Worker Practices Bioassay compliance removal process



BRUCE A

# Management Oversight

- Focus on VVR corrective maintenance prior to outage
- Daily oversight of VVR operation and tritium levels during outage
  - Response to high tritium taking action instead of increasing REPs
- Munter performance as a daily metric
- Event review boards for excessive dose
- Focus on munter performance

42R

• Weekly ALARA Committee during outages

## Where we are going next....

- Focus on online internal dose
  - CSA is similar to the vault should see same performance
  - Daily review of internal dose implemented
  - Improve worker practices
- Implementation of continuous tritium monitoring in key areas of the station
  - General areas

42R

BRUC

Rooms with chronic tritium or probability of fluctuating results

## Where we are going next....

Examination of respiratory protection requirements

| Comparison of respiratory protection requirements for tritium |                       |                       |                       |  |  |
|---|-----------------------|-----------------------|-----------------------|--|--|
|   | Respirator            | Air supplied          | Plastic suit          |  |  |
| Bruce Power   | >1 MPCa,<br>< 10 MPCh | >1 MPCa,<br>< 10 MPCh | > 100 MPC, 10<br>MPCh |  |  |
| Wolsong   | > 1 MPCa              | 10 DACh               | 50 DACh               |  |  |
| Gentilly  | 2 MPCh                | 2 MPCh                | 10 MPCh               |  |  |
| TQNPC   | 1-5 MPC               | 5 – 10 MPC            | 10 MPC                |  |  |
| Cernevoda   |                       |                       | 20 DAC<br>8 DACh      |  |  |

42R

BRUCE A